

# Russell Hobbs®

INSTRUCTIONS AND WARRANTY



MODEL NO. RHFP04

RUSSELL HOBBS ELECTRIC FRYING PAN

Congratulations on purchasing our Russell Hobbs Electric Frying Pan. Each unit is manufactured to ensure safety and reliability. Before using this appliance for the first time, please read the instruction manual carefully and keep it for future reference.

## **FEATURES OF THE RUSSELL HOBBS ELECTRIC FRYING PAN**

- The Russell Hobbs Electric Frying Pan has a variable thermostat with six heat settings. This thermostat is removable and goes up to 200°Celsius.
- The scratch proof non-stick coating makes cleaning the frying pan quick, easy and convenient.
- The power indicator light on the thermostat indicates when the frying pan has reached the selected cooking temperature.
- The glass lid on the Russell Hobbs Electric Frying Pan makes it easy to monitor food while cooking.
- The non-slip feet on the frying pan ensure safety while cooking.
- The Russell Hobbs Electric Frying Pan is highly versatile, you can: Roast, Grill, Bake, and Simmer.

## **IMPORTANT SAFEGUARDS**


When using any electrical appliance, basic safety precautions should always be followed including the following:

1. Please read these instructions carefully before using this appliance.
2. Always ensure that the voltage on the rating label corresponds to the mains voltage in your home.
3. Incorrect operation and improper use can damage the appliance and cause injury to the user.
4. The appliance is intended for household use only. Commercial use invalidates the warranty and the supplier can not be held responsible for injury or damage caused when using the appliance for any other purpose than that intended.
5. Avoid any contact with moving parts.
6. Close supervision is required when any appliance is used near or by children or invalids.
7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
8. Children should be supervised to ensure that they do not play with the appliance.
9. Check the power cord and plug regularly for any damage. If the cord or the plug is damaged, it must be replaced by the manufacturer or a qualified person in order to avoid an electrical hazard.
10. Do not use the appliance if it has been dropped or damaged in any way. In case of damage, take the unit in for examination and/or repair by an authorised service agent

11. To reduce the risk of electric shock, do not immerse or expose the motor assembly, plug or the power cord to water or any other liquid.
12. Never immerse the unit in water or any other liquid for cleaning purposes.
13. Remove the plug from the socket by gripping the plug. Do not pull on the cord to disconnect the appliance from the mains. Always unplug the unit when not in use, before cleaning or when adding or removing parts.
14. The use of accessory attachments that are not recommended or supplied by the manufacturer may result in injuries, fire or electric shock.
15. A short cord is provided to reduce the hazards resulting from becoming entangled in or tripping over a longer cord.
16. Do not let the cord hang over the edge of a table or counter. Ensure that the cord is not in a position where it can be pulled on inadvertently.
17. Do not allow the cord to touch hot surfaces and do not place on or near a hot gas or electric burner or in a heated oven.
18. Do not use the appliance on a gas or electric cooking top or over or near an open flame.
19. Use of an extension cord with this appliance is not recommended. However, if it is necessary to use an extension lead, ensure that the lead is suited to the power consumption of the appliance to avoid overheating of the extension cord, appliance or plug point. Do not place the extension cord in a position where it can be pulled on by children or animals or tripped over.
20. This appliance is not suitable for outdoor use. Do not use this appliance for anything other than its intended use.
21. DO NOT carry the appliance by the power cord.
22. Do not leave this appliance unattended during use. Always unplug the unit when not in use or before cleaning.
23. Always operate the appliance on a smooth, even, stable surface. Do not place the unit on a hot surface.
24. Ensure that the switch is in the "Off" position after each use.
25. The manufacturer does not accept responsibility for any damage or injury caused by improper or incorrect use, or for repairs carried out by unauthorised personnel.
26. In case of technical problems, switch off the machine and do not attempt to repair it yourself. Return the appliance to an authorised service facility for examination, adjustment or repair. Always insist on the use of original spare parts. Failure to comply with the above mentioned pre-cautions and instructions, could affect the safe operation of this machine.

27. **NOTE:** This unit becomes hot during use. Only use the handles provided to move the unit or lid.  
Do not move or lift the unit while in use.
28. When oil is heated to high temperatures, flammable gasses are released. Do not expose a flame to these gasses as this could cause a fire. Do not cover the frying pan when heating oil.
29. Do not use metal utensils in this frying pan. The metal utensils will damage the non-stick surface. Use wooden or heat-proof plastic utensils instead.

## PARTS DIAGRAM



1. Glass lid with steam vent and handle
2. Brushed stainless steel housing
3. Non-stick cooking surface
4. Stainless steel handles
5. Adjustable temperature probe

## OPERATING INSTRUCTIONS

1. Unpack the frying pan, taking care not to drop the frying pan or glass lid.
2. Rinse the cooking area of the frying pan and the glass lid in warm, soapy water. Rinse well with clean water and dry thoroughly.
3. Place the frying pan on a clean, dry, stable surface.
4. Ensure the control knob is in the "OFF" position, and is facing upwards. Insert the temperature probe into the side of the frying pan, into the receptacle located underneath the one handle.
5. Plug the unit into the wall socket and switch on the wall socket.
6. Turn the temperature control knob to your desired heat setting, from "WARM" to 200°C. The indicator light will turn on.
7. When the frying pan reaches the selected heat setting, the indicator light will turn off, and you can start using the frying pan. **DO NOT** leave the frying pan on without food or liquid inside once preheating is finished. This will damage the unit.

8. After use, turn the temperature control knob to the "OFF" position. Turn the wall socket off as well, and then unplug the frying pan from the wall socket.

## **CLEANING AND MAINTENANCE**

- This appliance is for household use only and is not user-serviceable.
- Do not open or change any parts by yourself. Please refer to a qualified electrical service department or return to the supplier if servicing is necessary.
- Always remember to unplug the unit from the electrical outlet when not in use and before cleaning. Ensure that the temperature control knob is in the "OFF" position, and is unplugged from the frying pan.
- To clean the frying pan, rinse the cooking area of the frying pan and the glass lid in warm, soapy water. Rinse well with clean water and dry thoroughly.
- Do not use bleach or other abrasive substance or solvents to clean your appliance as it can be damaging to the finish.
- To remove stubborn spots/marks, wipe the surfaces with a cloth slightly dampened in soapy water or mild non-abrasive cleaner. Rinse and dry a clean, dry, soft cloth.

## **STORING THE APPLIANCE**

- Unplug the unit from the wall outlet and clean all the parts as instructed above. Ensure that all parts are dry before storing.
- Store the appliance in its box or in a clean, dry place.
- Never store the appliance while it is still wet or dirty.
- Never wrap the power cord around the control prong.

## **SERVICING THE APPLIANCE**

There are no user serviceable parts in this appliance. If the unit is not operating correctly, please check the following:

- You have followed the instructions correctly
- That the unit has been wired correctly and that the wall socket is switched on.
- That the mains power supply is ON.
- That the plug is firmly in the mains socket.

If the appliance still does not work after checking the above:

- Consult the retailer for possible repair or replacement. If the retailer fails to resolve the problem and you need to return the appliance, make sure that:

- The unit is packed carefully back into its original packaging.
- Proof of purchase is attached.
- A reason is provided for why it is being returned.

If the supply cord is damaged, it must be replaced by the manufacturer or an authorised service agent, in order to avoid any hazard. If service becomes necessary within the warranty period, the appliance should be returned to an approved Amalgamated Appliance (Pty) Ltd service centre. Servicing outside the warranty period is still available, but will, however, be chargeable.


## CHANGING THE PLUG

Should the need arise to change the fitted plug, follow the instructions below.

**This unit is designed to operate on 230V current only. Connecting to other power sources may damage the appliance. Connect a three-pin plug as follows:**

The wires in this mains lead are coloured in accordance with the following code:

Green/Yellow = Earth  
Blue = Neutral  
Brown = Live



**PLEASE AFFIX YOUR PROOF OF PURCHASE/RECEIPT HERE  
IN THE EVENT OF A CLAIM UNDER WARRANTY THIS RECEIPT MUST BE PRODUCED.**

**WARRANTY**

1. Tedex Trading (Pty) Limited ("Tedex") warrants to the original purchaser of this product ("the customer") that this product will be free of defects in quality and workmanship which under normal personal, family or household use and purpose may manifest within a period of 1 (one) year from the date of purchase ("warranty period").
2. Where the customer has purchased a product and it breaks, is defective or does not work properly for the intended purpose, the customer must notify the supplier from whom the customer bought the product ("the supplier") thereof within the warranty period. Any claim in terms of this warranty must be supported by a proof of purchase. If proof of purchase is not available, then repair, and/or service charges may be payable by the customer to the supplier.
3. The faulty product must be taken to the supplier's service centre to exercise the warranty.
4. The supplier will refund, repair or exchange the product in terms of this warranty subject to legislative requirements. This warranty shall be valid only where the customer has not broken the product himself, or used the product for something that it is not supposed to be used for. The warranty does not include and will not be construed to cover products damaged as a result of disaster, misuse, tamper, abuse or any unauthorised modification or repair of the product.
5. This warranty will extend only to the product provided at the date of the purchase and not to any expendables attached or installed by the customer.
6. If the customer requests that the supplier repairs the product and the product breaks or fails to work properly within 3 (three) months of the repair and not as a result of misuse, tampering or modification by or on behalf of the customer, then the supplier may replace the product or pay a refund to the customer.
7. The customer may be responsible for certain costs where products returned are not in the original packaging, or if the packaging is damaged. This will be deducted from any refund paid to the customer.

**TEDELEX TRADING (PTY) LTD**  
www.amap.co.za  
011 490-9600 (Jhb)  
031 792-6000 (Dbn)  
021 535-0600 (CT)

