





Russell Hobbs

Smart in the kitchen...



classic toaster

instructions





Read the instructions and keep them safe. If you pass the toaster on to anyone else, pass on the instructions too.

Remove all packaging, but keep it till you're satisfied the toaster is working.

important safeguards

Follow basic safety precautions, including:

- 1 The toaster must only be used by or under the supervision of a responsible adult.
- 2 Don't put the toaster in water or any other liquid, don't use it in a bathroom, near water, or outdoors.
- 3 Sit the toaster upright on a firm, level, heat-resistant surface.
- 4 Don't put it on or near anything that could be damaged even by moderate heat.
- 5 If overcooked, bread may burn. Don't use the toaster near or below curtains or other combustible materials, and watch it while it's in use.
- 6 The area round the toasting slots gets hot – don't touch!
- 7 Route the cable so it doesn't overhang, and can't be caught or tripped over accidentally.
- 8 The toaster must not be operated by an external timer or remote control system.
- 9 When using a single toasting slot, don't let anything get into the other slot, as both slots will be "live" when the bread carriage handle is lowered.
- 10 Don't let the toasting slots become covered during toasting, or while the toaster is still hot.
- 11 If bread gets jammed, unplug the toaster, let it cool down fully, then carefully remove the bread that's jamming it. Don't use anything sharp, such as a knife or fork, you may damage the elements.
- 12 Don't toast sandwiches or buttered items, the fillings or the butter may burn.
- 13 Don't use torn, curled, or misshapen bread, you may jam the toaster.
- 14 Unplug the toaster when not in use, before moving and before cleaning. Let it cool down fully before cleaning and storing away.
- 15 Clean the crumbs out of your toaster frequently. A build up of crumbs is unhygienic, and could cause a fire hazard.
- 16 Don't use the toaster unless the crumb tray is in place.
- 17 Keep the toaster and the cable away from sources of heat.
- 18 Don't use the toaster for any purpose other than those described in these instructions.
- 19 Don't use the toaster if it's damaged or malfunctions.
- 20 If the cable is damaged, return the toaster, to avoid hazard.



household use only

before using for the first time

Before using the toaster for the first time, you need to cure the elements. This will remove their protective coating.

This may smell a bit, but it's nothing to worry about. Just make sure the room is well ventilated.

Check that there's nothing in the slots, turn the browning control to max, and operate the toaster without bread.

When it's done, leave it to cool down fully, then you can use it normally.





toasting bread

- 1 Sit the toaster upright on a firm, level, heat-resistant surface.
- 2 Don't put it on or near anything that could be damaged even by moderate heat.
- 3 Route the cable so it doesn't overhang, and can't be caught or tripped over accidentally.
- 4 If overcooked, bread may burn. Don't use the toaster near or below curtains or other combustible materials, and watch it while it's in use.
- 5 Put the plug into the power socket. Switch the socket on, if it's switchable.
- 6 Turn the browning control to the required setting (min = light, max = dark).
- 7 Put bread into the toasting slots (maximum thickness 25mm).
- 8 Press the bread carriage handle down fully – it'll only lock down if the toaster is connected to the electricity supply.
- 9 When it's done, the toast will pop up, and the elements will turn off.
- 10 The area round the toasting slots gets hot – don't touch!

extra lift

After toasting small items (bagels, crumpets, etc.) the bread carriage handle may be raised further, to allow them to be removed more easily.

eject ▲

To stop toasting, press the ▲ button. The toast will pop up, and the elements will turn off.

frozen bread ❄️

This takes the guesswork out of toasting frozen bread.

- 1 Leave the browning control at the setting you use with normal, unfrozen bread.
- 2 Put the frozen bread into the slots, lower the bread carriage handle, to start the toaster, then press the ❄️ button.
- 3 The toasting time will be altered automatically to give the same degree of browning you get with unfrozen bread.
- 4 The light will come on, and the elements will heat up.
- 5 When it's done, the toast will pop up, the light will go out, and the elements will turn off.

reheating toast

When reheating toast, use a low setting, otherwise you'll burn your toast. Don't reheat buttered toast, it may catch fire. Only reheat plain, unbuttered toast.

hints and tips

- ❄️ If you're toasting more than one slice of bread, make sure the slices are of similar size, thickness and freshness, otherwise they'll brown differently.
- ❄️ Old (yesterday's) bread contains less moisture than fresh bread, so makes crisper toast.
- ❄️ Old or thin bread cooks faster than fresh or thick bread, so you should use a lighter setting.
- ❄️ Sweet bread products (tea cakes, fruit loaf, etc.) brown much more quickly than ordinary bread, so should be toasted on a lighter setting.





changing the fitted/molded plug


Should the need arise to change the fitted/molded plug, follow these instructions:

mains (AC) operation

This unit is designed to operate on 230V- 240V current only. Connecting to other power sources may damage the unit.

connect three-pin plug as follows:

The wires in this mains lead are coloured in accordance with the following code: Green/Yellow = Earth Blue = Neutral Brown = Live



service

There are no user serviceable parts in this appliance. If the appliance is not operating correctly, please check that:

1. You have followed the instructions correctly.
2. Is the plug or cord are not damaged in any way?
3. Are the mains power supply On.

If the appliance still does not work:

In the first instance, consult your retailer for possible repair or replacement. If your retailer fails to solve your problem and you need to return the appliance, make sure that:

1. The unit is packed carefully back into its original packaging.
2. Proof of purchase is attached.
3. Give the reason why you are returning it.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agents in order to avoid a hazard. If service becomes necessary within the warranty period the appliance should be returned to an approved Amalgamated Appliances (Pty) Ltd service centre. Servicing outside the warranty period is still available, however it will be chargeable.





**PLEASE AFFIX YOUR PROOF OF PURCHASE/RECEIPT HERE.
IN THE EVENT OF A CLAIM UNDER WARRANTY, THIS RECEIPT MUST BE
PRODUCED.**

WARRANTY

Amalgamated Appliances (Pty) Limited ("the Supplier") warrants to the original purchaser of this product ("the Customer") that this product will be free of defects in material and workmanship which under normal, personal, family or household purpose manifest themselves within a period of 365 days from the date of purchase or in respect of commercial or professional purposes, manifest themselves within a period of 90 days from the date of purchase. Any claim in terms of the warranty must be supported by a proof of purchase. If such proof is not available, then notwithstanding anything to the contrary herein, the Supplier's normal charge for service and/or spares will be payable by the Customer upon collection of the repaired product. If a claim is made in terms of the aforesaid warranty within the first 7 days from the date of purchase, the faulty product will be exchanged (provided that the product is in its original packaging with all accessories). Failing return of the product within 7 days, the Supplier's liability shall be limited on return to the Supplier of the product or parts thereof, to the replacement or repair (in the sole discretion of the Supplier, or its duly authorised service dealer) of the product to eliminate any defect in workmanship or materials found to be due exclusively to any acts or omissions on the parts of the Suppliers, of which defects the Supplier shall have been notified in writing by the Customer within the aforesaid warranty period. The warranty provided herein and the obligations of the Supplier as aforesaid are in lieu of, and the Customer waives, all other warranties, guarantees, conditions or liabilities, express or implied, arising by law or otherwise, including without limitation, any obligation of the Supplier in respect of any injury, loss or damage (direct, indirect or consequential) arising out of the use of, or inability to use, this product and whether or not occasioned by the Supplier's negligence (gross or otherwise) or any act or omission on its part. The warranty does not include and will not be construed to cover products damaged as a result of disaster, misuse, abuse or any non-authorised modification of the product. The warranty does not include replacement of light bulbs, heater bars, paper bags or any glass, plastic bowl or jug or other expendables. During the warranty period the product should be taken to a service centre of the Supplier or one of its duly authorised service agents. The Supplier neither assumes nor authorises any other person to assume for it, any additional liability in connection with the sale or servicing of its products.

AMALGAMATED APPLIANCES (PTY) LTD.

**29, HERONMERE ROAD
BOOYSENS, JOHANNESBURG
2016**

**TEL NO. (011) 490 9000
FAX NO. (011) 490 9399**

**CAPE TOWN
DURBAN**

Win prizes on line: www.russellhobbs.co.za

**P O BOX 39186
BOOYSENS
JOHANNESBURG
2016**

**TEL NO. (021) 535-0600
TEL NO. (031) 792-6000**

439-092

