

## vertical steaming

Remove wrinkles from furnishing fabrics, curtains, without taking them down, and from hanging clothes.


20. Check there's adequate ventilation behind the fabric to be steamed, otherwise moisture may build-up, resulting in mildew.


21. Check there's nothing behind the fabric which may be damaged by steam.

22. Check that pockets, cuffs, or turn-ups are empty.

23. Check there's water in the water tank.

24. Set the temperature control to max, and the steam control to x.

25. Hold the iron close to (but not touching) the garment or fabric, and press the  button.

26. You may have to press the  button a few times to activate the pump.

27. Leave 4 seconds between each shot, to let more steam build-up.

## after use

28. Turn the temperature control to min, the steam control to x, then unplug the iron.

29. Hold it over a sink, turn it upside down and drain it.

**caution** The water may be hot.

30. Sit the iron on its heel to cool, then wipe off any moisture, then wind the cable round the heel.

31. Store the iron upright, to avoid soleplate corrosion.

## self clean

To prevent a build-up of scale in your iron, use the self clean button regularly, at least once a month in normal water areas, more often in hard water areas.

1. Turn the steam control to x and the temperature control to max.

2. Fill the water tank to max.

3. Sit the iron on its heel and plug it in. The ready light will come on.

4. When the ready light goes out, unplug the iron.

5. Hold the iron over a sink, then turn it till it's horizontal (fig 9).

**caution** look out for hot water and steam.

6. Press the self clean button, keep it pressed, and gently move the iron back and forth.

fig 7





fig 8



fig 9



7. The escaping water and steam will wash scale through the soleplate, and into the sink.

8. Release the self clean button when the water tank is empty.

9. Sit the iron on its heel to cool, then wipe off any moisture, then wind the cable round the heel.

## anti-scale

The anti-scale agent incorporated in the iron helps prevent the build-up of scale in your iron. Don't use any descaling compound, as this will destroy the anti-scale agent.

## cleaning

Unplug the iron and let it cool down fully.

Wipe the body and soleplate with a soft damp cloth.


Remove soleplate deposits with a drop of clear vinegar on a cloth. Wipe the vinegar off with a damp cloth.

Don't scratch the soleplate, don't put the iron in liquid, and don't use harsh or abrasive cleaners or solvents.

## connection

The product must be earthed. It has a Earth (green/yellow) 13A BS1362 fuse in a 13A BS1363 plug.

To replace the plug, fit the

green/yellow wire to  or E, the blue

wire to N, and the brown wire to L.


Fit the cord grip.

If in doubt, call an electrician.

Don't use a non-rewireable/moulded

plug unless the fuse cover js in place.

If you remove the plug, dispose of it.



## service

The product isn't user-serviceable. If it's not working, read the instructions, check the plug fuse and main fuse/circuit breaker. If it still doesn't work, consult the store you bought it from.

## guarantee

Defects affecting product functionality appearing within one year of purchase will be corrected by replacement or repair provided the product is used and maintained in accordance with the instructions. Your statutory rights are not affected. Documentation, packaging, and product specifications may change without notice.


Customer Service ([service@salstoneurope.com](mailto:service@salstoneurope.com))

Salton Europe Ltd, Failsworth, Manchester M35 0HS UK

[www.esalstoneurope.com](http://www.esalstoneurope.com)

Telephone 0845 658 9700 (local rate number)

# Russell Hobbs



## steamglide 1800

## iron

### instructions and guarantee

Read the instructions and keep them safe. Pass them on if you pass the iron on. Remove all packaging, but keep it till you're satisfied the iron is working.

### important safeguards

Follow basic safety precautions, including:


1. Don't put the iron in liquid, don't use it in a bathroom, near water, or outdoors.
2. The iron must only be used by or under the direct supervision of a responsible adult.
3. Don't iron clothing while it's being worn. You'll burn or scald the wearer (don't laugh, I've seen it done).
4. Don't touch the soleplate, keep clear of the steam coming from it.
5. Empty the iron carefully, it may contain hot water.
6. Don't use the iron in the vicinity of children.
7. Don't use the iron for any purpose other than those described in these instructions.
8. Don't leave the iron unattended while plugged in, or while it's standing on the ironing board. It could be knocked over by you, by a child, or by a pet.
9. Unplug the iron to fill, to clean, and after use.
10. Don't fill the iron directly from the tap, use the jug.
11. Don't fill past max, or water may escape in use.
12. Leave the iron upright to cool before cleaning.
13. Keep the cable away from hot parts.
14. Keep the iron away from sources of heat.
15. Route the cable so it can't be caught or tripped over.
16. Keep the iron upright when you're not ironing, and when you store it away.
17. Don't use accessories or attachments other than those we provide.

18. Don't use the iron if it's damaged or malfunctions. If the cable is damaged, return the iron to avoid hazard.

19. Don't scratch the soleplate, avoid buttons, zips, etc. A thermal fuse will blow if the iron overheats. The iron will stop working, and must be returned for repair.

### household use only

#### before use for the first time

Don't worry if the iron smokes a bit at first, it'll stop. Iron an old bit of cotton, to clean the soleplate. Press the  button 3 or 4 times, to check it out.

#### preparation

Check for textile care symbols, iron fabrics needing low heat first, then work up to those needing most heat.

fig 1





fig 3




### steam ironing

9. Set the temperature control to **••**, **•••**, or **max**.
10. Turn the steam control to your required setting **1** = low steam, **3** = high steam (**x** = no steam).
11. Wait till the ready light goes out, then start ironing.


### spray (dry or steam ironing)

**nb** Water spotting affects some fabrics, test on a hidden part of the fabric.

12. Check there's water in the tank.
13. Lift the iron off the fabric, and aim the nozzle.
14. Press the spray  button. You may have to press it two or three times to pump water through the system.

### shot of steam

This works in dry or steam ironing, as long as there's water in the tank, and the temperature is high enough.

15. Check there's water in the water tank.
16. Set the temperature control to **••**, **•••**, or **max**.
17. Lift the iron slightly off the fabric and press the  button. You may have to press it two or three times to pump water through the system.

18. Leave 4 seconds between shots, to let steam build-up.

### dry ironing

**nb** Empty the water tank before dry ironing for over 20 minutes, to prevent spontaneous bursts of steam.


19. Turn the steam control to **x**.
20. Wait till the ready light goes out, then start ironing.

### filling

The iron is tap-water tolerant, but if your water is very hard, use distilled water marketed as suitable for irons.

1. Unplug the iron.
2. Turn the temperature control to min, turn the steam control to **x** (fig 3).
3. Sit the iron on its soleplate.
4. Pour water from the jug into the water inlet. Don't try to fill it too fast. The air in the water tank has to be able to get out, to let the water in, otherwise the water may back up and overflow.
5. Don't fill past **max**, or water may escape in use.
6. Wipe up any spillage.

fig 2



### switch on

7. Sit the iron on its heel and plug it in. The ready light will come on.

### temperature settings

label markings

temperature setting = •

cool – nylon, acrylics, polyester = ••

warm – wool, polyester mixtures = •••

hot – cotton, linen = ••••

don't iron = 

**nb** If the directions on the garment label differ from the table, follow the directions on the label.

8. Turn the temperature control so the required temperature setting is next to the mark (fig 3). The ready light goes out when the iron reaches working temperature, then cycles on and off.




fig 4




fig 5



fig 6